



Frese PV-SIGMA Compact

- DK **Montagevejledning**
- RUS **Монтажная инструкция**
- EN **Mounting instructions**


Danmark · Tlf. +45 58 56 00 00
 Россия · Тел. +7 (812)459 49 19
 UK · Tel. +44 (0)1704 896012



- DK Skitse af varmesystem med Frese PV-SIGMA Compact
- RUS Пример системы отопления с Frese PV-SIGMA Compact
- EN Outline of a heating system with Frese PV-SIGMA Compact




- DK Differenstrykregulatoren PV Compact indstilles vha. en 4 mm sekskantnøgle, ud fra grafen for den valgte ventildimension. Den dynamiske indreguleringsventil SIGMA Compact indstilles vha. håndtaget, ud fra grafen eller fra Frese's APP.
- RUS Регулятор перепада давления PV Compact настраивается при помощи 4мм шестигранного ключа, настройка определяется по диаграммам подбора. Ограничитель расхода SIGMA Compact настраивается вращением рукоятки, настройка определяется по диаграммам расхода.
- EN The differential pressure control valve PV Compact is set by means of a 4mm hexagonal key, from the flow rate graphs for the valve dimension in question. Balancing valve SIGMA Compact, is set by the hand wheel, from the flow rate graphs or from the Frese APP.




- DK Monter T-stykke i SIGMA Compact og forbind kappilarrør mellem ventilerne.
- RUS Установить комби-ниппель в SIGMA Compact и соединить регуляторы импульсной трубкой
- EN Mount the T-piece in SIGMA Compact and connect the capillary tube between the two valves

Frese PV-SIGMA Compact DN15 Low

Frese PV Compact DN15, 5-30 kPa




Frese SIGMA Compact DN15 Low




Frese PV-SIGMA Compact DN15 High

Frese PV Compact DN15, 20-60 kPa




Frese SIGMA Compact DN15 High




Frese PV-SIGMA Compact DN20 Low

Frese PV Compact DN20, 5-30 kPa




Frese SIGMA Compact DN20 Low




Frese PV-SIGMA Compact DN20 High

Frese PV Compact DN20, 20-60 kPa




Frese SIGMA Compact DN20 High




Frese PV-SIGMA Compact DN25 Low

Frese PV Compact DN25, 5-30 kPa




Frese SIGMA Compact DN25 High




Frese PV-SIGMA Compact DN25 High

Frese PV Compact DN25L, 20-80 kPa




Frese SIGMA Compact DN25 High




Frese PV-SIGMA Compact DN32

Frese PV Compact DN32, 20-80 kPa




Frese SIGMA Compact DN32




Frese PV-SIGMA Compact DN40

Frese PV Compact DN40, 20-80 kPa




Frese SIGMA Compact DN40



Frese PV-SIGMA Compact DN50

Frese PV Compact DN50, 20-80 kPa



Frese SIGMA Compact DN50

